

# Stickymat Application



## Before You Begin Application

1. Do not use on substrates that require high breathability
2. Ensure that the substrate is fully cured/ dried out
3. Clear any dust on the substrate using a vacuum or soft broom
4. Choose the correct grade of Stickymat – LD, MD or HD

## Applying



1. Peel back approximately 12 inches of release paper from Stickymat adhesive layer



2. Attach adhesive side to the surface to be protected



3. Working in pairs, roll out the mat progressively peeling off the remaining release paper and firmly smoothing out on contact with surface. For large areas use a dry paint roller on an extension pole to press down



4. Ensure that each new length of mat overlaps on the white strip (shown) to bond and seal to the previous length



5. Continue process until entire area has been covered



6. Your surface is now protected by T.F.P.'s 'TecDura Stickymat'!