

BREATHABLE DURAMAT/LD STICKYMAT APPLICATION SHEET

BEFORE YOU BEGIN APPLICATION:

1. Ensure that substrate has had time to cure/dry out
2. Clear away any dust/debris from the area where Duramat/LD Stickymat will be laid
3. Always test a small, non visible area of the substrate to ensure adhesion and performance
4. Select correct mat for purpose (Duramat or LD Stickymat)

Step 1

Brush away any dirt and debris from the area where the mat will be applied



Step 2

Peel away approximately 30cm of release paper from adhesive backing and attach to substrate



Step 3

Pull the release paper away from the adhesive backing allowing the protective mat to seal to the surface



Step 4

Ensure each new length overlaps the previously laid mat by 4cm to complete full seal



Step 5

Repeat steps 2 to 4 until the total of the required substrate is covered



Step 6

You are now TecDura covered and can start working immediately!

